


Hive Radiator Valve

You never have to heat an empty room again with our smart radiator valve



Product overview

The Hive Radiator Valve is our new smart thermostatic radiator valve. It's a self-regulating valve that controls the flow of hot water into an individual radiator so you can manage your heating room by room. And because ours is smart, you can adjust it from your smartphone or tablet through the Hive app, whether you have Hive Active Heating or not.

Product features

- **Room by room heating control**
- **Schedules** – set and follow a schedule
- **Save money** and energy by not heating empty rooms
- **Set the exact temperature you want each room** to be in degrees, rather than selecting a setting between 1-5
- **Easy to install** – simply unscrew your existing TRV head and replace it with a Hive Radiator Valve
- **Frost Protect and Holiday mode**
- **Hive Actions** – choose from a number of pre-set actions or create your own
- **Measure and regulate room temperature**
- **Adjust temperature directly on your Hive Radiator Valve**
- **2 years' battery life** (2 x AA batteries)
- **Works with any type of heating system**, provided there are plumbed radiators with TRV valve bodies
- **Requires a hub** (but not a Hive thermostat)

Box includes

- Hive Radiator Valve (head only)
- 2 x AA batteries
- Quick start guide
- RA Adaptor
- M30 adaptor
- Hex Key

What you can do with it

Our Hive Radiator Valves let you manage your heating room by room, all from your smartphone. So you never have to heat an empty room again.

Avoid heating empty rooms

Never waste money heating empty rooms. For example, keep your bedroom cool during the day then schedule your radiator to turn up before you head to bed.

Manage it all from your smartphone

If you realise you've left the heating on in a room you don't need, just turn the radiator off via your Hive app, without affecting the heating in the rest of your home.

Let the sun shine

Sunshine super-heating one side of the house? Hive Radiator Valves monitor the temperature of the room so they'll only turn up the heat as and when it's needed.

Get into a tight spot

Fit Hive Radiator Valves on hard-to-reach radiators so you're able to control them with ease, and without the need for furniture wrestling.

Product & packaging specs

Product Description	Hive Radiator Valve
Barcode	5054347004240
Product Code	UK7004240
Packaged Weight	0.2478kg
Packaged Height	110mm
Packaged Width	79mm
Packaged Depth	59mm
Batteries Included	2 x AA batteries
Batteries needed to power the product?	Yes

What you will need

Works with any type of heating system, provided there are plumbed radiators with TRV valve bodies. Requires a Hive Hub but not a Hive thermostat.

Extra info

- Hive Radiator Valves are a great addition to your Hive Active Heating
- Will work with your existing thermostat
- If you already have TRVs installed: They're really easy to install – they screw on in place of your existing valve heads
- If you don't have TRVs installed: You'll need to upgrade the fittings on your radiators before fitting them but being able to control how you're heating different rooms could make a significant difference to your heating bills
- Not suitable for electric radiators & storage heaters
- Simple self-install